

# INDUSTRY CARE

## ELECTROSTATIC CONTROL PRODUCTS

### I.C. HAND LOTION (CLEANROOM)

#### PRODUCT DESCRIPTION

I.C. Hand Lotion is formulated to meet the needs of any cleanroom, static-sensitive, or sterile environment. Its risk-free formula is hypoallergenic, fragrance-free, dye-free, greaseless, and has no VOC's or contaminants that compromise your cleanroom or sterile environment. Vitamins A, D, and E, along with a blend of nourishing succulents, are added to heal past damage and prevent contact dermatitis caused by repeated glove-use and handwashing.

#### DIRECTIONS FOR USE:

Use before gloving to protect hands from drying and cracking.

#### USES:

- Use as pre-gloving lotion to avoid contact dermatitis
- Use to improve grounding to wrist wraps for PCB work
- Use to hydrate and seal dry skin in a cleanroom or sterile environment.

#### APPLICATIONS:

Healthcare, Office, Industrial, Education, Government, Electronics, Facility Maintenance, Nursing Homes

#### WORKPLACE CERTIFICATIONS & SPECIFICATIONS

Helps Meet ANSI ESD-TR20.20

NSF E4 Certified for Food Processing Plants

Glove Compatibility Tested

#### FEATURES & BENEFITS

Limitless Accessibility	Free of compromising ingredients in cleanroom, sterile, or medical environments
No VOC's	Lacks compromising volatile organic compounds
Equipment Safe	Will not affect keyboards, displays, or static sensitive devices
Risk-Free Formula	Free of dyes, lanolin, silicon, glycerin, and mineral oils
Fragrance-Free	Odorless and free of artificial fragrances
Moisturizing	Revitalizing formula restores skin health and complexion
Comfort Care	Relieves dry skin caused by diseases like xerosis, eczema, dermatitis and more
Preventative Care	Helps to avoid contact dermatitis from repeated glove-use or handwashing
Nourishing Vitamins	Vitamins A, D, and E stimulate cells and are naturally anti-inflammatory
Succulent Infusion	Helps to maintain and improve the skin's hydration, tone, and elasticity
Hypoallergenic	Free of ingredients likely to cause an allergic reaction
Skin Softening	Protects from damage caused by skin cracking, exposure, or dryness
Dermatologist Tested	Clinically proven to be an effective moisturizing agent
Pre-Glove Compatible	Use before putting on Nitrile, Latex or Vinyl gloves
Non-Greasy	Dries instantly with no oil-tracking on surfaces or equipment
Non-Toxic	Free of toxic solvents, emollients, and other harmful ingredients
ESD Packaging	ESD Safe Bottle options to keep with you at your workstation
Food Facility Compliant	Product has been independently evaluated and trace amounts of the product are not expected to cause any adverse toxicological effects
PCB Safe	Does not contain chemicals that may adversely affect solderability or cause corrosion of electronic components
ESD Standards	Helps meet ESD-TR20.20 by hydrating the skin and making a better connection to ESD wrist straps



VOC-Free



Mineral Oil-Free



Paraben-Free



Lanolin-Free



Silicone-Free



Cruelty-Free



#### INGREDIENT LIST

Purified DI Water, Propylene Glycol, , Glyceryl Stearate (and) PEG-100 Stearate, Stearic Acid, Octyl Stearate (and) Octyl Palmitate (and) Dioctyl Adipate, Cetyl Alcohol, Triethanolamine, Phenoxyethanol (and) Ethylhexyl-glycerin, Triethanolamine, Disodium EDTA,, Agave Tequilana Leaf (Blue Agave), Simmondsia Chinensis (Jojoba) Seed, Aloe Barbadosensis Leaf Juice (Aloe Vera), Vitamins A, D, & E

## REGULATORY

This product is a cosmetic product, manufactured and labeled in compliance with the Federal, Drug and Cosmetic Act issued by the Food and Drug Administration (FDA). R&R Lotion is an FDA and EPA Registered and Audited Facility.

- FDA Establishment Identifier: 3004167955
- EPA Facility Number: 91651-AZ-001
- FDA Drug Code Prefix - 59555

## SAFETY DATA SHEETS

For safety, environmental, handling, first aid and disposal information, please refer to the Safety Data Sheet which can be downloaded from SDS library on <https://rrlotion.com/msds/>

## QUALITY ASSURANCE

**Facility Standards** – R&R Lotion facilities follow Current Good Manufacturing Practice (cGMP) and/or Cosmetic GMP requirements.

**Material Standards** – Incoming raw materials must undergo quality inspection and are efficacy tested prior to being used for manufacturing.

**Equipment Standards** – All equipment and tools utilized are cleaned and sanitized both before and after use once verified by QA using sterility testing equipment.

**Formula Testing** – Formulas developed by R&R Lotion undergo a series of tests and approvals to verify stability, product efficacy, and preservative effectiveness.

**Finished Product Testing** – Every batch produced by R&R Lotion must go through physical, chemical, and microbiological testing prior to being approved for distribution. This includes in-house lab testing of appearance, color, odor, density, pH, and viscosity, followed by third-party active ingredient efficacy and product sterility testing.

**Product Traceability** – The collection and annual review of all raw materials, finished goods, process controls, and formulas allows for consistent control and correction in good manufacturing and documentation procedures.

## SIZES & PART NUMBERS

PART NUMBER	SIZE	CASE	UPC
ICL-8-CR-ESD	8oz. ESD Blue Bottle with Pump	24	666080847470
ICL-8-CR	8oz. Bottle with Snap Cap	24	666080847463
ICL-16-CR	16oz. Bottle with Pump	12	666080847654
ICL-16-CR-ESD	16oz. ESD Blue Bottle with Pump	10	666080848033
ICL-32-CR	32oz. Bottle with Pump	12	666080847487
ICL-GAL-CR	1 Gallon Bottle with Pump	4	666080847494

## APPEARANCE

Product Type	Lotion
Color	White
Odor	Odorless
pH	6.5-8.5
Viscosity	3000-7000 Spindle #4 @20RPM

## STORAGE TEMPERATURE & SHELF LIFE

This product has a shelf life of at least 24 months from the date of manufacture when stored unopened at room temperature. The product should not exceed 32°F – 150°F to remain stable and effective.

## COMPATIBILITY TESTING

**NSF E4 Certified**– This product is acceptable for use as a moisturizing product (E4) in and around food processing area.

**Clinically and Dermatologist Tested**– The human repeat insult patch test (HRIPT), which is the standard human clinical test used for personal care and pharmaceutical products, is used to help predict the likelihood for induced allergic contact dermatitis (ACD) of topically applied products.

**Ground Resistivity Tested**– Confirmed improvement for wrist to ground connectivity when applied as a pre-gloving moisturizer. As mentioned by ANSI/ESD S1.1 standards.

## QUICK CHEMICAL REGULATORY REFERENCES

Prop 65	No Known Substances
TSCA	No Known Substances
SARA	No Known Substances
REACH	No Known Substances
RoHS	No Known Substances

This information and all further technical advice are based upon our present knowledge and experience. Customer is responsible for determining whether products and the information in this document are appropriate for Customer's use. The claims made may not have been approved for use in all countries. R&R Lotion Inc assumes no obligation or liability for the information in this document. No warranties are given; all implied warranties of merchantability or fitness for a particular purpose are expressly excluded. Dated: 08/01/2022